



1-Connect the Easy Start Orange wire with the CX3 compressor run capacitor white wire

2- Connect the Easy Start Black wire in a 3-way splice with the CM C red wire

3-Disconnect the CM R blue wire and splice it into the Easy Start Brown wire

4-Where you just removed the blue wire in the previous step, connect the Easy Start White wire