



On your wiring diagram the compressor will have C, S and R. On the compressor CSR will be on the cover over these wires.
 C=Common S=Start R=Run Each wire will be under a letter and can be traced from the compressor.

1. Before Easy Start installation!
All connectors used must be 600VAC rated.
 If present in your system all start component connections and wires need to be removed.

2. Put Easy Start Black with compressor common (C) in a 3-way splice.

3. Put Easy Start Orange on the run-capacitor Herm (H) position.
 The compressor start wire will also be present on the Herm post.

4. Remove compressor run (R) from the run-capacitor and Splice to Easy Start Brown. [see red X]

5. Where you removed the last connection Put Easy Start White on the run-capacitor.