

1-Connect the ES Orange wire with the RED compressor run cap wire

2-Connect the ES Black wire in a 3-way splice with the compressor Black C wire

3-Remove the compressor run R white wire from the run cap & splice it into the ES Brown wire

4-Where you just removed the white wire in step 3, connect the ES White wire

**CAUTION:** 1-If you have the optional start cap & PTCR., they must be removed (yellow x's) before installation.

2-In step three, make sure that you pull off the compressor R white wire and not the pressure switch white wire from the run cap.

