

**NOTE: First remove the small starter on top of the run capacitor & the WHT/RED wire. Make sure the BLU/RED wire is plugged into the run capacitor HERM post.**

**1-Connect the Easy Start Orange wire on the run capacitor HERM post with the BLUE/RED wire.**

**2-Make a 3-way splice with the compressor BLU/BLK common wire & the Easy Start Black wire.**

**3-Remove the WHT/BLK run wire from the run capacitor C post and splice it into the Easy Start Brown wire.**

**4-Where you just removed the wire in step 3, connect the Easy Start White wire.**

