

1-Connect the Easy Start Orange wire with the run capacitor S RED herm wire

2-Connect the ES Black wire in a splice anywhere along compressor C Blue wire

3-Remove the compressor R white wire from the run capacitor, & splice it into the ES Brown wire

4-Where you just removed the R white wire in step 3, connect the Easy Start White wire

