

- 1-Connect the Easy Start Black wire in a 3-way splice with the COMP C black wire
- 2-Connect the Easy Start Orange wire on the COMP S red wire run CAP post
- 3-Disconnect the COMP R white wire from the run CAP post & splice it into the Easy Start Brown wire
- 4-Where you just removed the white wire in step 3, connect the Easy Start White wire