



**1. Before Easy Start installation! All connectors used must be 600VAC rated.**

If present in your system all start component connections and wires need to be removed.

**2. Put Easy Start Black with compressor common (C) on where you see the arrow -or- make a 3-way splice.**

**3. Put Easy Start Orange on the run-capacitor Herm (H) position.**

**4. Remove compressor run (R) [see red X on W-wire] from the run-capacitor and Splice to Easy Start Brown.**

**5. Where you removed the last connection Put Easy Start White.**

