



1-Connect the Easy Start Orange wire with the CAP YE (yellow) wire

2-Make a 3-way splice with the Easy Start Black wire and the COMP C RD (red) wire

3-Remove the BU (blue) COMP R wire from the CAP and splice it into the ES Brown wire

4-Where you just removed the BU (blue) wire in step 3, connect the Easy Start White wire